



# **HPT435 Base TRIUMPH-1 Rover**

## **Configuration Example**

**Version 1.1**

**Last Revised March 19, 2009**

All contents in this manual are copyrighted by JAVAD GNSS.  
All rights reserved. The information contained herein may not be used, accessed, copied, stored, displayed, sold, modified, published, or distributed, or otherwise reproduced without express written consent from JAVAD GNSS.

# BASE & ROVER CONFIGURATION EXAMPLE

## HPT435 as a Base Configuration

1. Connect the TRIUMPH-1 receiver to computer. See for details the TRIUMPH-1 Operator's Manual.
2. Connect the external HPT435 UHF radio to receiver's port B with cable Accessory Data-Ser cable, ODU-7/D15 (1.8 m) p/n 14-578108-01.



**Figure 4-1. Accessory Data-Ser cable, ODU-7/D15**

**Note:** The port B is optional. Make sure you have such option purchased.

3. Power the HPT435. You can use the rechargeable battery type Power Sonic PS-12400 or similar and Accessory Power Cable, PL-700/Battery Clips (2.5m), p/n14-578111-01.




**Figure 4-2. Power cable, PL-700/Battery clips**

**Warning:** *Powering HPT435 please observe polarity!*

*For PS-12400 battery charging use the charger "Power-Sonic Chargers" type PSC-124000A.*


4. Turn on the TRIUMPH-1 receiver.
5. Start ModemVU.

6. Select *HPT435* and click OK (Figure 4-3).




**Figure 4-3. ModemVU. Options window**

7. Select the port the TRIUMPH-1 receiver is connected to and click *Connect* (Figure 4-4).



**Figure 4-4. ModemVU. Connection**

8. In the *Radio Link* tab set the following parameters, and click *Apply* (Figure 4-5):




**Figure 4-5. Radio Link tab settings**

- Protocol: Simplex Transmitter
- Frequency (MHz): 406 to 470
- Output power (dBm/W): 45/35.00
- Modulation Type: DQPSK
- Link Rate: 19200
- Link Space: 25.0 kHz
- Forward Error Corrections: ON
- Scrambling: ON


9. Quit ModemVU by clicking *Exit* button.

- 10. Start TriVU. Select port the TRIUMPH-1 receiver is connected to and click OK (Figure 4-6).




**Figure 4-6. TriVU. Selecting port**

- 11. Click *Configuration* ► *Receiver*.
- 12. In the *Base* tab click the *Get from receiver* button. Reference geodetic coordinates appear. Click *Apply* (Figure 4-7).



**Figure 4-7. Base tab**

13. In the *Ports* tab set the Port B *Output mode* to RTK CMR, and click *Apply*, then OK (Figure 4-8).



**Figure 4-8. Rover tab**

## **TRIUMPH-1 internal UHF radio as a Rover Configuration**

1. Connect the receiver and computer as described in TRIUMPH-1 Operator's Manual.
2. Start ModemVU.

## Base & Rover Configuration Example


TRIUMPH-1 internal UHF radio as a Rover Configuration

3. Select *Triumph 1X Internal Radio* and click OK (Figure 4-9).



**Figure 4-9. ModemVU. Options window**

4. Select the port receiver is connected to and click *Connect* (Figure 4-10).




**Figure 4-10. ModemVU. Connection**

5. Select the *ON* mode for *Radio*, click *Apply* and click *Connect Radio* button (Figure 4-11).




**Figure 4-11. ModemVU TRIUMPH Internal Radio selection**

6. In the *Radio Link* tab set the following parameters, and click *Apply* (Figure 4-12):



**Figure 4-12. Radio Link tab settings**

- Protocol: Simplex Receiver
  - Frequency (MHz): 406 to 470
  - Output power (dBm/W): 30/1.00
  - Modulation Type: DQPSK
  - Link Rate: 19200
  - Link Space: 25.0 kHz
  - Forward Error Corrections: ON
  - Scrambling: ON
7. Quit ModemVU by clicking *Exit* button.
8. Start TriVU. Select port the receiver is connected to and click OK (Figure 4-6).



**Figure 4-13. TriVU. Selecting port**




## Base & Rover Configuration Example

TRIUMPH-1 internal UHF radio as a Rover Configuration


9. Click *Configuration* ► *Receiver*.

10. In the *Positioning* tab set RTK fixed Positioning Mode, then click *Apply* (Figure 4-14).




**Figure 4-14. Positioning tab**

11. In the *Rover* tab set Positioning Mode to RTK fixed mode (Figure 4-15), then click *Apply*:




**Figure 4-15. Rover tab**

12. In the *Ports* tab set the *Input* mode for port D to CMR, then click *Apply* and OK (Figure 4-16).



**Figure 4-16. Ports tab**

13. The receiver will obtain the RTK Fixed solution (Figure 4-17).



**Figure 4-17. TriVU. RTK fixed**

## Base & Rover Configuration Example

TRIUMPH-1 internal UHF radio as a Rover Configuration